MOTUL VALVE & INJECTOR CLEANER DIESEL

Diesel injector and intake valve cleaner
Curative additive to add to Diesel fuel

TYPE OF USE

MOTUL VALVE & INJECTOR CLEANER DIESEL is a curative additive designed to be used in all types of Diesel injection systems, with direct or indirect injection, naturally aspirated or turbocharged, with or without DPF (Diesel Particulate Filter) and with or without SCR (Selective Catalytic Reduction) systems.

VALVE & INJECTOR CLEANER DIESEL is a Diesel additive compatible with Biodiesel fuels such as B7 (7% Biodiesel) and B10 (10% Biodiesel).

MOTUL VALVE & INJECTOR CLEANER DIESEL effectively cleans dirtying and clogging which appear in the whole Diesel fuel injection system:

- injector nozzle fouling
- dirtying of inlet valves and combustion chambers
- gumming in the injection pump and injectors

MOTUL VALVE & INJECTOR CLEANER DIESEL provides a perfect lubrication during cleaning phase and prevents removed micro-particles from depositing. Moreover, it prevents from Diesel fuel oxidation and micro-organisms formation.

PERFORMANCES

A clean fuel system is a necessary condition for an effective engine functioning. MOTUL VALVE & DIESEL SYSTEM CLEAN allows to:

- Restore engine power and performance
- Reduce fuel consumption and pollutant emissions at the exhaust (smoke, fumes…). To be recommended before the technical inspection.
- Improve cold starts and drivability comfort
- Increase lifetime of fuel systems and after treatment systems

RECOMMENDATIONS

Pour one whole can of MOTUL VALVE & INJECTOR CLEANER DIESEL in the Diesel tank before refueling, the fuel system will be then completely cleaned, from the tank to the injector and the combustion chamber.

A can is sufficient for tanks up to 50 liters. Do not exceed the recommended proportion.

We retain the right to modify the general characteristics of our products in order to offer to our customers the latest technical development.

Product specifications are definitive from the order which is subject to our general conditions of sale and warranty.

MOTUL - 119 Bd Félix Faure - 93303 - Aubervilliers Cedex - BP 94 - FRANCE - Tel: 33 1 48 11 70 00 - Fax: 33 1 48 33 28 79 - www.motul.com

MOTUL VALVE & INJECTOR CLEANER DIESEL

Diesel injector and intake valve cleaner
Curative additive to add to Diesel fuel

If necessary, proceed to 2 successive treatments.

To maintain the benefits of cleaning, use MOTUL SYSTEM KEEP CLEAN DIESEL regularly.

SECURITY

Refer to the MSDS sheet and the information mentioned on the product label.

We retain the right to modify the general characteristics of our products in order to offer to our customers the latest technical development.

Product specifications are definitive from the order which is subject to our general conditions of sale and warranty.

MOTUL - 119 Bd Félix Faure - 93303 - Aubervilliers Cedex - BP 94 - FRANCE - Tel: 33 1 48 11 70 00 - Fax: 33 1 48 33 28 79 - www.motul.com

MOTUL VALVE & INJECTOR CLEANER DIESEL

Diesel injector and intake valve cleaner
Curative additive to add to Diesel fuel

We retain the right to modify the general characteristics of our products in order to offer to our customers the latest technical development.

Product specifications are definitive from the order which is subject to our general conditions of sale and warranty.

MOTUL - 119 Bd Félix Faure - 93303 - Aubervilliers Cedex - BP 94 - FRANCE - Tel: 33 1 48 11 70 00 - Fax: 33 1 48 33 28 79 - www.motul.com